


Quick Start Guide



Unpack Your System

- 1) Active speaker
- 2) Passive speaker
- 3) AC power adapter
- 4) IR remote control
- 5) Pair of speaker grills
- 6) Pair of speaker pads
- 7) 3.5mm to 3.5mm cable
- 8) 3.5mm to RCA "Y" cable
- 9) USB A to USB B cable
- 10) RJ50 speaker interconnect cable
- 11) 2.5mm Allen wrench
- 12) This Quick Start Guide





Pick Your Speaker Locations

Speakers sound best when they point toward your ears. The T0 *Plus* has been designed to make this easy, whether used on a desk or in a room.

The support is optional for desktop usage, but we recommend leaving it installed if you have space to improve portability. For spaced constrained applications the supplied 2.5mm Allen wrench can be used to remove the support (reinstall the screws in the amplifier plate if the support is removed). The support can also be moved to the other side of the cabinet, as the T0 Plus works with the passive radiator facing either up or down. Note that when the passive radiator faces down the support must face down too; the speaker cannot be allowed to rest on the passive radiator.

Desktop Usage

Place the speakers on the supplied pads with the supports and passive radiators facing up. Position the active speaker with the connections on the right side of your seated position (this can be changed in software). Try to get your speakers at equal distance on each side.


In-Room Usage

Place the speakers on the supplied pads with the supports and passive radiators facing down. Position the active speaker with the connections on the right side of your listening position (this can be changed in software). Ideally your speakers should be at equal distance from your best listening position on each side, and approximately at ear level when you are seated.



Connect the Speakers


The included speaker interconnect cable with modular RJ50 connectors makes this a "snap"!













Plug in the AC adapter to the wall and to the active speaker.






Connect Your Audio Source

Your T0 Plus speakers support analog, USB, optical, and Bluetooth wireless connections.

- 1) Analog Connect your source using the included using 3.5mm to 3.5mm cable or 3.5mm to RCA cable as appropriate for your source component.
- 2) USB Connect your computer to the T0 *Plus* using the supplied USB A to USB B cable. Select the Vanatoo T0 *Plus* in your computer's audio settings.
- Optical Connect your source component to the Vanatoo T0 Plus using a Toslink optical cable.
- 4) Bluetooth
 - a. Press and release the "Pair-Prog" button on the rear of the active speaker, or press "Enable" and then "BT Pair" on the remote control.
 - b. Ensure Bluetooth is turned-on on your source device and pair with the Vanatoo T0 *Plus*.
 - c. Ensure your source device is connected to the Vanatoo T0 *Plus* over Bluetooth and play music!






Install the Grills

Grills come in individual plastic bags. Simple magnetic mounting (no or little alignment necessary). Can go either way such that the "Vanatoo" logo is upright on the bottom.



Listen to Music!

In most applications you can set the T0 *Plus* volume control to 100% and adjust the volume up/down from your source (Computer, Bluetooth device, etc).





Remote Control

The included IR Remote Control is especially handy when your T0 *Plus* is used with a TV, or for switching sources, adjusting bass and treble, etc. Note that you must hit the "Enable" button to enable the other buttons inside the rectangular box for 30 seconds.



Optional Settings

The T0 *Plus* has a lot of setup options, such as enabling the speakers to play mono, disabling sleep mode, varying the LED brightness, connecting a subwoofer and alternate bass profiles for room placement. Go to www.vanatoo.com/ support/downloads to download the user manual for a full description of the T0 *Plus* and its setup options.

CONGRATULATIONS!! That's it! We hope you enjoy your Vanatoo Transparent Zero *Plus* powered speakers.

For additional setup up information, connectivity options, and the troubleshooting guide, check out the Transparent Zero *Plus* Owner's Guide or visit us at www.vanatoo.com.

Contact Us

Email: support@vanatoo.com